Tips for an Accurate Measurement

- Ensure the sample does not contain any debris.
- Whenever the cuvette is placed into the checker, it must be dry outside and free of fingerprints, oil and dirt.
- Wipe the cuvette thoroughly with HI731318 microfiber cleaning cloth or a lint-free cloth prior to insertion.
- Shaking the cuvette can generate bubbles, causing higher readings. To obtain accurate measurements, remove such bubbles by swirling or by gently tapping the cuvette.
- Do not let the reacted sample stand too long after reagent has been added, as accuracy will be affected.
- Discard the sample immediately after the reading has been taken or the glass might become permanently stained.

Battery Replacement

- To save the battery, the checker shuts down after 20 minutes of non-use and 4 minutes after reading.
- A fresh battery lasts for a minimum of 5000 measurements. When the battery is drained, the instrument displays "bAd" then "bAt", and turns off.
- To replace the battery, follow the next steps:
- 1. Press and hold the ON/OFF button to turn the checker off.
- 2. Turn the instrument upside down and use a screwdriver to unfasten the screw and remove the battery cover.



- 3. Remove the old battery, replace it with a new 1.5V AAA battery, inserting the negative end first.
- 4. Replace the battery cover, fasten and tighten the screw.

Accessories

Reagent Sets

 \otimes

HI707-25 Reagents for 25 Nitrite Low Range tests

Other Accessories

HI707-11	Nitrite Low Range certified standard kit
HI731225	Cuvette black cap for ${\sf Checker}^{^{(\!\!\!\!R\!)}}$ HC colorimeters (4 pcs.)
HI731318	Cloth for wiping cuvettes (4 pcs.)
HI731321	Glass cuvette and seal cap for $Checker^{^\circledast}HC$ colorimeters (4 pcs.)
HI731353	Cuvette seal cap for Checker® HC colorimeters (4 pcs.)
HI740028P	1.5V AAA battery set (12 pcs.)
HI93703-50	Cuvette cleaning solution 230 ml

Certification

All Hanna Instruments conform to the CE European Directives. Disposal of Electrical & Electronic Equipment. The product should not be treated as household waste. Instead hand it over to the appropriate collection point for the recycling of electrical and electronic equipment which will conserve natural resources.

Disposal of waste batteries. This product contains batteries, do not dispose of them with other household waste. Hand them over to the appropriate collection point for recycling.

Ensuring proper product and battery disposal prevents potential negative consequences for the environment and human health. For more information, contact your city, your local household waste disposal service, the place of purchase or go to www.hannainst.com.

X

Recommendations for Users

Before using this product, make sure it is entirely suitable for your specific application and for the environment in which it is used. Any variation introduced by the user to the supplied equipment may degrade the checker's performance. For yours and the checker's safety do not use or store it in hazardous environments.

Warranty

HI707 Checker[®]HC is warranted for a period of one year against defects in workmanship and materials when used for its intended purpose and maintained according to instructions. This warranty is limited to repair or replacement free of charge. Damage due to accidents, misuse, tampering or lack of prescribed maintenance is not covered. If service is required, contact your local Hanna Instruments Office. If under warranty, report the model number, date of purchase, serial number and the nature of the problem. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the checker is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization (RGA) number from the Technical Service department and then send it with shipping costs prepaid. When shipping any product, make sure it is properly packaged for complete protection.

Hanna Instruments reserves the right to modify the design, construction, or appearance of its products without advance notice.

All rights are reserved. Reproduction in whole or in part is prohibited without the

written consent of the copyright owner. Hanna Instruments Inc., Woonsocket,

Rhode Island, 02895, USA.

INSTRUCTION MANUAL

HI707 Nitrite Low Range



HANNA instruments

Dear Customer,

Thank you for choosing a Hanna Instruments product. Please read this instruction manual carefully before using the Checker®HC handheld colorimeter. For more information about Hanna Instruments and our products, visit www.hannainst.com or e-mail us at sales@hannainst.com. For technical support, contact your local Hanna Instruments Office or e-mail us at tech@hannainst.com.

Preliminary Examination

Remove the Checker[®]HC handheld colorimeter and accessories from the packing material and examine it carefully. If you require any further information, please contact Hanna Instruments technical support team.

Each H1707 is delivered in a case with custom insert and is supplied with:

- Sample cuvette and cap (2 pcs.)
- Nitrite Low Range reagent starter kit (reagents for 6 tests)
- 1.5V AAA Alkaline battery (1 pc.)
- Instruction manual

Note: Save all packing material until you are sure that the Checker®HC handheld colorimeter works correctly. Any damaged or defective item must be returned in its original packing material with the supplied accessories.

General Description & Intended Use

HI707 Nitrite Low Ranae handheld checker is designed to accurately determine nitrite levels in applications such as water quality control checks or analysis of wastewater and aquariums.

HI707 features a sinale-button operation system and is easy to use. The large LCD is easy to read and the auto shut-off feature assures the battery life will not he drained

Specifications

Range	0 to 600 ppb NO_2^-N
Resolution	1 ppb
Accuracy	$\pm 20~\text{ppb}~\pm 5\%$ of reading @ 25 °C (77 °F)
Light source	Light Emitting Diode @ 470 nm
Light detector	Silicon photocell
Method	Adaptation of the EPA Diazotization Method 354.1. The reaction between nitrite and the reagent causes a pink tint in the sample.
Environment	0 to 50 $^\circ\text{C}$ (32 to 122 $^\circ\text{F});$ max. 95% RH non-condensing
Battery type	1.5V AAA Alkaline
Auto shut-off	After 20 minutes of non-use and 4 minutes after reading
Dimensions	86 x 61 x 37.5 mm (3.4 x 2.4 x 1.5″)
Weight	64 g (2.3 oz)

Functional Description & LCD Display



Measurement Procedure

blinkina

· Press the ON/OFF button to turn the checker . \... on. All seaments will be displayed for a few seconds, followed by "Add", "C.1" with "Press"

Add Press

8

Add Press

[]:]4

9:59

120

- Fill the cuvette with 10 mL of unreacted sample and replace the cap. Insert the cuvette into the checker and close the cap.
- Press the ON/OFF button. When the display shows "Add", "C.2" with "Press" blinking, the checker is zeroed
- Remove the cuvette, unscrew the cap and add the content of one packet of HI707-0 Nitrite Low Range reagent. Replace the cap and shake gently for about 15 seconds.
- Insert the cuvette into the checker and press and hold the ON/OFF button. The display will show the countdown prior to the measurement. Alternatively, wait 15 minutes and press the button. Note: Reaction times between 10 and 15 minutes are displayed in minutes and reaction times under 10 minutes are displayed in minutes and seconds.
- · When the timer ends the checker will perform the reading. The instrument displays the nitrogen-nitrite (NO₂-N) concentration in ppb. To convert the displaued concentration to nitriteion concentration (NO_2) , multiply the reading by 3.29. To convert the NO₂⁻N concentration to sodium nitrite (NaNO₂) multiply the reading by 4.93. The checker automatically turns off 4 minutes after readina.

Errors & Warnings

The checker shows clear warning messages when erroneous conditions appear and when measured values are outside the expected range. The information below provides an explanation of the errors and warnings, and the recommended action to be taken.

Light High: There is an excess amount of ambient light reaching the detector. Please check the preparation of the zero cuvette.



Light Low: There is not enough light to perform a measurement Please check the preparation of the zero cuvette.



Inverted Cuvettes: The sample and the zero cuvettes are inverted. Swap the cuvettes and repeat the measurement.

Under Ranae: A blinking "O" indicates that the sample absorbs less light than the zero reference. Check the measurement procedure and make sure to use the same cuvette for reference (zero) and measurement.

Ü

600

inu

Over Ranae: Maximum concentration value displayed blinking indicates the measured value is outside the limits of the method. Verify that the sample does not contain any debris. Dilute the sample and repeat the measurement.

Battery Low: Battery level is too low for the checker to function properly. Replace the battery with a new one.

Replace the battery with a new one and restart the checker.







