## Instruction Manual

# HI 3833 **Phosphate Test Kit**



Dear Customer,

Thank you for choosing a Hanna Product.

Please read this instruction manual carefully before using the chemical test kit. It will provide you with the necessary information for correct use of the kit.

Remove the chemical test kit from the packing material and examine it carefully to make sure that no damage has occurred during shipping. If there is any noticeable damage, notify your Dealer or the nearest Hanna office immediately.

Each kit is supplied with:

- 1 beaker (20 mL):
- 1 color comparator cube;
- HI 3833-0 powder reagent (100 pcs).

Note: Any damaged or defective item must be returned in Experiment its original packing materials.

### **SPECIFICATIONS**

Range	0 to 5 mg/L (ppm) $PO_4^{3-}$
Smallest Increment	1 mg/L (ppm) PO <sub>4</sub> <sup>3-</sup>
Analysis Method	Colorimetric
Sample Size	10 mL
Number of Tests	100
Case Dimensions	220x145x55 mm (8.7x5.7x2.1")
Shipping Weight	160 g (6 oz.)

## SIGNIFICANCE AND USE

Phosphates are widely introduced into the environment from such sources as agricultural fertilizers, cleaning and laundering products, boiler water conditioners, and drinking water treatment aids.

At high levels, phosphates stimulate the growth of photosynthetic organisms which may contribute to eutrophication of lakes, rivers, and ponds. This makes it important to monitor and control phosphate discharges into the environment.

Phosphates can be classified as ortho, condensed or organically bound. As with existing test kits on the market, the Hanna Phosphate Test Kit will only determine ortho phosphate levels.

NOTE: ma/L is equivalent to ppm (parts per million).

## **CHEMICAL REACTION**

The orthosphosphate level in mg/L (or ppm) is determined by a colorimetric method. Ammonium molybdate and potassium antimonyl tartrate react in acid medium with orthophosphate to form a phosphomolybdate complex, that is reduced to intensely colored molybdenum blue by ascorbic acid. The color intensity of the solution determines the phosphate concentration.

### **INSTRUCTIONS**

READ THE ENTIRE INSTRUCTIONS BEFORE USING THE KIT

 Remove the cap from the plastic vessel. Rinse the plastic vessel with water sample, fill it to 10 mL mark




• Add 1 packet of reagent HI 3833-0



 Replace the cap and mix solution \ until solids dissolve.



 Remove the cap and transfer the solution into the color comparator cube. Let set for 1 minute.



• Determine which color matches the solution in the vessel, and record the results as mg/L (or ppm) PO<sub>4</sub><sup>3</sup>-.



### REFERENCES

- 1987 Annual Book of ASTM Standard, Volume 11.01 Water (1). Pages 651-652.
- Standard Methods for the Examination of Water and Wastewater, 16th Edition, 1985, Pages 445-446.

## **HEALTH AND SAFETY**

The chemicals contained in this kit may be hazardous if improperly handled. Read Health and Safety Data Sheet before performing this test.